SONY

Operation Software

BZS-7060A

Supplement 1
Software Version 5.10

English

Manual to be supplemented

BZS-7060A User's Guide
1st Edition
Software Version 5.00 and Later

Digital Video Switcher System

DVS-7250 System

BZS-7060A (WW)
3-868-078-**01**(1)

Sony Corporation
Broadcasting & Professional Systems Company

Printed in Japan
1999.08.13
© 1999

This User's Guide describes additional functions and changes in Version 5.10 of the BZS-7060A Operation Software.
Use the pages of this supplement to replace the corresponding pages in your copy of the User's Guide.

Functions newly supported from BZS-7060A version 5.10

The following functions are newly supported from version 5.10 of the BZS-7060A Operation Software.

Function	See page
Wipes using a BKDS-7370 board	4-110
Still files operation using a BKDS-7444 board	6-18
Show key functions	14-30
VTR program play mode	14-51
MODE 3 (Switching the operating mode of the Flexipad)	14-62
Settings for manipulating the snapshot attributes in the Flexipad section	14-64